ESCO Ultralok™ to Super V® Cross-Reference

Ultralok® Pattern	Ultralok™ Description	Super V® Pattern	SV Part #
U20C	Penetration/Abrasion point for excavators	N/A	N/A
U20S	Standard point for excavators & loaders	V19SYL	5120994
U20AP	Penetration/Abrasion point for loaders	V19AD	5120966
U20F	Flared point for clean up and GP digging	V19TF	5119943
U20T	Twin pick point for extreme penetration	V19TVY	5119944
U20P	Extreme penetration point	V19VY	5119947
5854-U20	1.00"/25mm excavator adapter	5854-V19	5119952
833-U20	1.00"/25mm excavator adapter (universal)	833-V19	5119953
8802-U20	1.00"/25mm flush mount loader adapter	8802-V19	5119954
3877-U20	1.20"/30mm 1-1/2 Top Leg Loader Adapter	3877-V19	5119951
U25C	Penetration/Abrasion point for excavators	N/A	N/A
U25S	Standard point for excavators & loaders	V23SYL	5119958
U25AP	Penetration/Abrasion point for loaders	V23AD	5120968
U25F	Flared point for clean up and GP digging	V23S5F	5119957
U25T	Twin pick point for extreme penetration	V23TVY	5119959
U25P	Extreme penetration point	V23VY	5119962
U25A	Heavy abrasion point for loaders	V23AR	5122949
U25H	Heavy abrasion point for excavators	V23SHV	5122948
5849-U25	1.25"/30mm excavator adapter	3880-V23	5119967
5854-U25	1.00"/25mm excavator adapter	5854-V23	5121847
3870-U25	1.25"/30mm Bottom Leg excavator adapter	3870-V23	5126250
8803-U25	1.25"-1.38"/30-35mm flush mount loader adapter	8803-V23	5120996
3808-U25	1.25"/35mm 1-1/2 Top leg loader adapter	3808-V23	5119966
U30C	Penetration/Abrasion point for excavators	V29SDX	5119988
U30S	Standard point for excavators & loaders	V29SYL	5119982
U30AP	Penetration/Abrasion point for loaders	V29AD	5119984
U30F	Flared point for clean up and GP digging	V29S6F	5119986
U30T	Twin pick point for extreme penetration	V29TVY	5122834
U30P	Extreme penetration point	V29VY	5119985
U30A	Heavy abrasion point for loaders	V29AR	5121683
U30H	Heavy abrasion point for excavators	V29SHV	5121361
8831-U30	1.5-1.75"/40-45mm flush mount loader adapter	8831-V29	5120958
802A-U30	1.50"/40mm 1-1/2 Top leg loader adapter	802A-V29	5121848
8833-U30	1.50"/40mm 1-1/2 Top Leg loader adapter	8833-V29	5122213
5850-U30	1.50"/40mm 1-1/2 Bottom leg excavator adapter	5850-V29	5119973
5849-U30	1.25"/30mm Bottom leg excavator adapter	5849-V29	5128258
3871A-U30	1.38"/35mm Bottom leg excavator adapter	3871-V29	5129867
3881B-U30	1.38"/35mm 1-1/2 Bottom leg excavator adapter	3881A-V29	5119989

U35C	Penetration/Abrasion point for excavators	V33SDX	5119998
U35S	Standard point for excavators & loaders	V33SYL	5119981
U35AP	Penetration/Abrasion point for loaders	V33AD	5119994
U35F	Flared point for clean up and GP digging	V33S7F	5119996
U35T	Twin pick point for extreme penetration	V33TVY	5122835
U35P	Extreme penetration point	V33VY	5119995
U35A	Heavy abrasion point for loaders	V33AR	5121684
U35H	Heavy abrasion point for excavators	V33SHV	5120970
5855-U35	1.5"/40mm 1-1/2 Bottom leg excavator adapter	5855-V33	5119976
3872A-U35	1.5"/40mm Bottom leg excavator adapter	3872A-V33	5120973
3810B-U35	1.75"/45mm 1-1/2 Bottom leg excavator adapter	3810A-V33	5120971
8831-U35	1.5-1.75"/40-45mm flush mount loader adapter	8831-V33	5120974
8833-U35	1.50"/40mm 1-1/2 top leg loader adapter	8833-V33	5124063
U40C	Penetration/Abrasion point for excavators	V39SDX	5120952
U40S	Standard point for excavators & loaders	V39SYL	5119980
U40AP	Penetration/Abrasion point for loaders	V39AD	5120948
U30F	Flared point for clean up and GP digging	V39S8F	5120950
U40T	Twin pick point for extreme penetration	V39TVY	5122836
U40P	Extreme penetration point	V39VY	5120949
U40A	Heavy abrasion point for loaders	V39AR	5121685
U40H	Heavy abrasion point for excavators	V39SHV	5120978
5856-U40	2.00"/50mm excavator adapter	5856-V39	5119979
3810B-U40	1.75"/45mm excavator adapter	3810A-V39	5120979
1837A-U40	2.00"/50mm 1-1/2 top leg loader adapter	1837A-V39	5121849
1812LA-U40	2.00"/50mm left hand loader adapter	1812LA-V39	5121850
1812RA-U40	2.00"/50mm right hand loader adapter	1812RA-V39	5121851
3882B-U40	1.50"/40mm excavator adapter	3882A-V39	5119999
3892-U40	2.00"/50mm flush mount loader adapter	3892-V39	5120960
U45H	Heavy abrasion point for excavators	V43SHV	5120983
U45S	Standard point for excavators & loaders	V43SYL	5119992
U45A	Heavy abrasion point for loaders	V43AR	5121686
U45AP	Penetration/Abrasion point for loaders	V43AD	5120954
U45P	Extreme penetration point	V43VY	5120955
U45T	Twin pick point for extreme penetration	V43TVY	5121780
U45F	Flared point for clean up and GP digging	V43S9F	5120984
U45C	Penetration/Abrasion point for excavators	V43SDX	5120957
1812L-U45	2.00"/50mm left hand loader adapter	1812L-V43	5121359
1812R-U45	2.00"/50mm right hand loader adapter	1812R-V43	5121360
1837A-U45	2.00"/50mm loader adapter	1837A-V43	5120999
8854-U45	2.00"/50mm straddle leg loader adapter	8854-V43	5124300
3811A-U45	2.25"/60mm1-1/2 Bottom Leg excavator adapter	3811A-V43	5122107
3810B-U45	1.75"/45mm 1-1/2 Bottom Leg excavator adapter	3810A-V43	5120945
5856-U45	2.00"/50mm excavator adapter	5856-V43	5119991
1810-U45	2.00"/50mm loader adapter (Cat)	1810-V43	5121869
1810R-U45	2.00"/50mm right hand loader adapter (Cat)	1810R-V43	5121870
1810L-U45	2.00"/50mm left hand loader adapter (Cat)	1810L-V43	5121871

U55C	Penetration/Abrasion point for excavators	V51SDX	5121902
U55S	Standard point for excavators & loaders	V51SYL	5121800
U55AP	Penetration/Abrasion point for loaders	V51AD	5121802
U55F	Flared point for clean up and GP digging	V51S10F	5121938
U55T	Twin pick point for extreme penetration	V51TVY	5121805
U55P	Extreme penetration point	V51VY	5121804
U55A	Heavy abrasion point for loaders	V51AR	5121900
U55H	Heavy abrasion point for excavators	V51SHV	5121897
5857A-U55	2.50"/65mm excavator adapter	5857A-V51	5121334
8801A-U55	2.00"/50mm excavator adapter	8801-V51	5120873
8813A-U55	2.50"/65mm loader adapter	8813A-V51	5120778
8813LA-U55	2.50"/65mm left hand loader adapter	8813LA-V51	5120779
8813RA-U55	2.50"/65mm right hand loader adapter	8813RA-V51	5120780
5870A-U55	2.50"/65mm straddle leg loader adapter	5870A-V51	5121228
3811A-U55	2.38"/60mm excavator adapter	3811-V51	5124591
3858A-U55	2.75"/70mm excavator adapter	3858-V51	5121761
4831A-U55	2.00"/50mm 2 Leg excavator adapter	4831A-V51	5121909
1852-U55	2.38"-2.50"/60mm-65mm Universal Flush mount loader adapter	1852-V51	5121089
U60C	Penetration/Abrasion point for excavators	V61SD	5124990
U60S	Standard point for excavators & loaders	V61SYL	5120672
U60AP	Penetration/Abrasion point for loaders	V61AD	5122789
U60F	Flared point for clean up and GP digging	V61TG	
U60T	Twin pick point for extreme penetration	V61TVP	5120753
U60P	Extreme penetration point	V61VX	5120752
U60A	Heavy abrasion point for loaders	V61AG	5120671
U60H	Heavy abrasion point for excavators	V61ARL	5120751
6805A-U60	3.50"/90mm excavator adapter	6805-V61	5120410
5898A-U60	3.12"/80mm excavator adapter	5898-V61	5120539
8845A-U60	3.00:/75mm excavator adapter	8845-V59	5122346
3858B-U60	2.75"/70mm excavator adapter	3858-V61	5120890
5857B-U60	2.50"/65mm excavator adapter	5857A-V59	5121330
3811A-U60	2.38"/60mm excavator adapter	3811-V61	5120889
5869B-U60	2.50"/65mm loader adapter	5869-V61	5121089
5869LB-U60	2.50"/65mm left hand loader adapter	5869L-V61	5121101
5869RB-U60	2.50"/65mm right hand loader adapter	5869R-V61	5121100
5870LB-U60	2.75"/70mm left hand straddle leg adapter	5870A-V61	5121099
5870RB-U60	2.75"/70mm right hand straddle leg adapter	5870A-V61	5121099
1856A-U60	3.00"/75mm loader adapter	1856-V61	5120892
1857LA-U60	3.00"/75mm left hand loader adapter	1857L-V61	5121104
1857RA-U60	3.00"/75mm right hand loader adapter	1857R-V61	5121105
1888C-U60	2.50"/65mm loader adapter	1888B-V59	5121865
4891A-U60	2.75"/70mm loader adapter	4891-V59	5121861
4890LA-U60	2.75"/70mm left hand loader adapter	4890L-V59	5121863
4890RA-U60	2.75"/70mm right hand loader adapter	4890R-V59	5121862
WN-U60	Weldon Nose	WN-V61	5120891